Optimeter Optical Fiber Meter

QUICK CARD

Updating Software via WiFi

This quick card outlines how to upgrade the Optimeter to the latest software revision using a WiFi connection to the internet.

EQUIPMENT REQUIREMENTS

Equipment Requirements:

• Optimeter

• WiFi Internet Connection

Figure 1: Equipment Requirements

CONNECT TO WIFI

1. Press the **ON/OFF** button to turn on the test set.

2. Press the **HOME** button to display the home screen.

Figure 2: Optimeter Home Screen

3. Tap the Connectivity icon to show the Connectivity menu.

4. Tap the **Wireless** icon to configure the WiFi connection:

   Figure 3: Connectivity Settings

   ➢ Set **Wlan Mode** to **Wireless Client.**

   ➢ Set **SSID** to the SSID of your network or Personal Hotspot and enter your **Key/Password**.

   ➢ Verify that an **IP Address** is dynamically assigned to the Optimeter.

5. Tap the **Exit** soft key to return to the Connectivity menu.

Figure 4: Wireless Settings

Optimeter Optical Fiber Meter

QUICK CARD

UPGRADE

1. Plug the Optimeter into AC power. You cannot update the software while running on battery.

2. Tap the **UPGRADE** Icon to show the Software Upgrade screen.

3. Verify **Address Type = Viavi Server.**

4. Tap the **Software Upgrade** soft key.

5. Tap the **Check available version** soft key.

6. A window will appear to verify that the server address is correct. Tap **Continue**.

7. Tap the **Start Upgrade** soft key.

8. Follow screen prompts to complete the software upgrade.

*Figure 5: Connectivity Menu*

Figure 6: Software Upgrade Menu

Figure 7: Software Upgrade Menu

Figure 8: Start Upgrade

Contact Us

**+1 844 GO VIAVI
(+1 844 468-4284)**

To reach the VIAVI office nearest you,
visit viavisolutions.com/contact